


Fluke SW90W FlukeView 示波表软件



主要特性

- For ScopeMeter(R) 190 Series II and 120 Series
- Windows XP/Vista/Windows 7/Windows 10
- Requires one free RS-232 port (COM port) or a free USB-Port
- Requires optional PM9080 RS-232 Adapter/Cable or an optional OC4USB-cable (190C Series, 120 Series)

Note: 190 Series II comes with USB-port and USB-cable included. For 190 Series II no additional hardware is required.

产品概述: Fluke SW90W FlukeView 示波表软件

FlukeView-1 software adds PC power to your Fluke ScopeMeter test tool


FlukeView-1 ScopeMeter software helps you get more out of your [ScopeMeter 190 Series II Test Tool](#) by:

- Documenting: Transfer screens, waveforms, and measurement data from the ScopeMeter Test Tool to your PC for printing, or to import data to other programs.
- Archiving: Store and retrieve waveforms with text annotations and create your own library for easy reference and comparison.

- Analysis: Gather valuable measurement data and enable cursor measurement to reveal relationship and conditions.

Extended recording of up to four user-selected measurements help you monitor and analyze slow moving signals and related events. Upload waveforms to the PC and use cursors for detailed measurements. Perform waveform analysis, including analyzing harmonics.

型号



Fluke SW90W

FlukeView 示波表软件



Fluke. 让您的工作畅通无阻。

福祿克測試儀器（上海）有限公司 電話：400-810-3435 ©2025 福祿克公司
06/2025
北京福祿克世祿儀器維修和服務有限公司 電
話：400-615-1563 未經許可，本文檔禁止修改
福祿克測試儀器（上海）有限公司上海維修中心 電
話：021-54402301, 021-54401908分機269
福祿克測試儀器（上海）有限公司深圳第一特約維修點
電話：0755-86337229